	/////// HEM	
FOLD 90°		
ᅵ뿌ᅵᄋᆡ	 Glue sparingly in centre only Trim sheet to dotted line CAREFULLY Centrepunch and Whitney Punch all holes 1/8" CAREFULLY cut out edges CAREFULLY Fold hems CHECK fit of base to lid sides (adjust fold line if necessary) CAREFULLY Fold edges Assemble lid and base Clamp in vise to put hinge holes as close to the back edge as possible Drill through with 1/8" Insert pop-rivet Remove paper with soap and water)— — — — — — — — — — — — — — — — — — —
	Design Updated 21-05-28 G Wellwood FOLD 90°	 -
HEM		